



Technical parameters:

1. Load-bearing hooks are required in the well. See the figure for the positions and load-bearing requirements. The hooks are only used for hoisting equipment during device installation
2. The door of the floor at the entrance adopts the mode of electrical interlock. If the door is not closed, the equipment cannot operate. The door of the floor cannot be opened until the equipment reaches the target floor
3. Hydraulic station has pressure detection device, when overload buzzer alarm, equipment stop running
4. The winding mode of the balanced wire rope is shown in the figure
5. Guide fasteners (Angle iron) shall be embedded in the well. Angle iron size is 100*100*8mm, fixed by M10 sleeve expansion bolt, the size is 10*120mm
6. The hook installation position is shown in the figure A and B (you can install one of them).

Time	17/03/2023	Details of fixing method and bearing hook
Name		
Draw		
Examination		
		A3
proportion 1:100		