A I-BEAM



This type is suitable for our own trolley



Usually,our trolley wheel have a inclination to suit to I-beam

B H-BEAM



This type H-beam is flat,and then we need to adjust wheel accordingly.